



Test Wizard Creator

Release Notes for Version 1.2.1

Welcome to release 1.2.1 of Viavi Test Wizard Creator for Windows. This document provides version numbers, a description of new features, and a list of unresolved issues associated with this release, unless otherwise specified.

Contents

Version Numbers	2
What's New in Version 1.2.1.....	2
Installation	2
Fixed Problems.....	3
Known Issues.....	3
Known Limitations	3
Technical Assistance	3

Version Numbers

Software Application Version

Test Wizard Creator	1.2.1
---------------------	-------

Compatible CellAdvisor Firmware Version

JD720C series	1.064.00x and after
---------------	---------------------

What's New in Version 1.2.1

- Added a setup task item of “General”

Installation

Hardware Requirement

- OS: Windows Vista, Windows 7, Windows 8 and higher – Windows 8 and higher recommended
- CPU: Core i-3 2GHz or higher
- Display resolution: 1208 x 800 and higher - 1920 x 1080 recommended
- USB 2.0 or 3.0
- 10/100/1000 LAN, Wi-Fi

To install Test Wizard Creator in your computer

- 1 Insert the USB drive that came with your CellAdvisor JD720C series into your computer. You can also download the latest software at <http://celladvisor.updatemyunit.net/>.
- 2 Navigate to the installation file named “TestWizardCreator_setup_1_2.exe”.
- 3 Double-click the installation file and follow the instructions on the screen.

To install a license in your instrument

- 1 Check the firmware version of your JD720C series if it is 1.064.00x or after. If yes, go to step 3. If not, go to step 2.
- 2 To install the compatible firmware, download the firmware file at the following URL and upgrade the firmware as instructed in the firmware release notes included in the firmware file: <http://www.viavisolutions.com/en/services-and-support/support/software-downloads-and-updates#Group-C>
- 3 In your instrument, go to **Mode > System > Instrument Settings**.
- 4 Tap the **Installable Options** button for **License**.
- 5 Enter a license number you have received at your purchase of the option.
- 6 Tap the **Apply** button.

Fixed Problems

- Fixed to enable the operation of 1Port Cable Loss in the measure mode.

Known Issues

- None

Known Limitations

- None

Technical Assistance

For assistance related to the use of your product, call or e-mail VIAVI Technical Assistance Center (TAC) in your region. For a current listing of TAC phone numbers and e-mail addresses, go to:

<http://www.viavisolutions.com/en/services-and-support/support/technical-assistance>

Document History

Revision	Date	Reason for revision
22109609 rev 001	Jun 01, 2016	Release Software Application Test Wizard Creator 1.1
22109609 rev 002	Jan 26, 2017	Release Software Application Test Wizard Creator 1.2
22109609 rev 003	Feb 14, 2017	Release Software Application Test Wizard Creator 1.2.1